

# **POLARSPA**

## **Hot tub using in winter**



**Thank you for your purchase composite tub TM "POLARSPA"**

Main features of using a hot tub with a stove in winter.

**BE SURE TO DRAIN THE WATER FROM THE HOT TUB WHEN USING IT IN THE FROZY AIR TEMPERATURES OUTSIDE.**

Otherwise, the stove may become unusable (rupture of the stove pipes). It is forbidden to drain the water from the tub until the fire in the stove and the ash completely cooled.

If it so happens that the water in the tub is frozen, this case it is FORBIDDEN to use the stove. The frozen water in the tub will not melt due to these actions, but the stove will burn out.

**Your actions:** wait until the ice in the tub melts naturally.

If there is a risk of water freezing in the nozzles, as well as in the pipes, make sure that the water can circulate freely.

It is recommended to clear the place around the tub from snow so that the bottom of the tub doesn't stand in the snow (to avoid swelling of the wooden lining of the tub due to prolonged exposure to a humid environment).

IN WINTER, WATER IS NOT ALLOWED TO FREEZE IN ANY PART OF THE AEROMASSAGE SYSTEM. DRAIN WATER FROM THE TUB WHILE IT IS WARM AND NOT FROZEN.

AFTER USING THE TUB, IT IS NECESSARY TO REMOVE THE REST OF WATER FROM THE SYSTEM - TO DO THIS, "BLEED" THE SYSTEM BY LETTING IT RUN WITHOUT WATER IN THE TUB (APPROXIMATELY 30 SECONDS).

*Taking care of you, POLARSPA team.*